


Ditec COMER

IP1830 • 2015-09-25

Istruzioni selettore di funzioni elettronico
Instructions for electronic function selector



ELECTRIC CONNECTIONS

KBISOR KBISTR KTENR	86KVB1NR	KVALNR KVALTR	GENERIC APPLICATION
COM [EL16]	COM [EL16]	COM [EL21]	COM [EL16-EL20]
G1 [94R]	G1 [EL16R]	G1 [EL21]	DO NOT USE
1R [94R]	1R [EL16R]	1 [EL21]	1 [EL16-EL20]
MR [94R] + 29 [EL16]	MR [EL16R] + 29 [EL16]	29 [EL21]	29 [EL16-EL20]



Entrematic Group AB
Lodjursgatan 10
SE-261 44, Landskrona
Sweden
www.ditecentrematic.com